


Tandy Acoustic Coupler 2 for use with Portable Computers

Cat. No. 26-3818

TANDY®



The Tandy Acoustic Coupler 2 enables your Portable Computer to be connected to a telephone that does not allow direct connection (such as a phone in a telephone booth or hotel room).

When using or handling the Acoustic Coupler 2, keep the following points in mind:

- Avoid excessive strain on the coupler cable. Place the coupler units as close to the telephone as possible. Do not tug on the cable.
- If you are not using the acoustic modem, make sure the DIN connector is disconnected from the computer.
- Do not use the Acoustic Coupler 2 with telephones other than rotary-dial or pushbutton types with standard or European-style handsets.
- While data is being received or transmitted through the coupler units, do not touch the coupler units or subject the cups to significant vibration and noise. This helps prevent data error. The same precautions should be observed with the desk or table upon which the coupler units are placed.
- The condition of the telephone line can disturb the transmission through the Acoustic Coupler 2. If the line disturbance breaks the modem connection, call again.

TERMS AND CONDITIONS OF SALE AND LICENSE OF TANDY COMPUTER EQUIPMENT AND SOFTWARE PURCHASED FROM RADIO SHACK COMPANY-OWNED COMPUTER CENTERS, RETAIL STORES AND RADIO SHACK FRANCHISEES OR DEALERS AT THEIR AUTHORIZED LOCATIONS

LIMITED WARRANTY

I. CUSTOMER OBLIGATIONS

- A. CUSTOMER assumes full responsibility that this computer hardware purchased (the "Equipment"), and any copies of software included with the Equipment or licensed separately (the "Software") meets the specifications, capacity, capabilities, versatility, and other requirements of CUSTOMER.
- B. CUSTOMER assumes full responsibility for the condition and effectiveness of the operating environment in which the Equipment and Software are to function, and for its installation.

II. LIMITED WARRANTIES AND CONDITIONS OF SALE

- A. For a period of ninety (90) calendar days from the date of the Radio Shack sales document received upon purchase of the Equipment, RADIO SHACK warrants to the original CUSTOMER that the Equipment and the medium upon which the Software is stored is free from manufacturing defects. **This warranty is only applicable to purchases of Tandy Equipment by the original customer from Radio Shack company-owned computer centers, retail stores, and Radio Shack franchisees and dealers at their authorized locations.** The warranty is void if the Equipment or Software has been subjected to improper or abnormal use. If a manufacturing defect is discovered during the stated warranty period, the defective Equipment must be returned to a Radio Shack Computer Center, a Radio Shack retail store, a participating Radio Shack franchisee or a participating Radio Shack dealer for repair, along with a copy of the sales document or lease agreement. The original CUSTOMER's sole and exclusive remedy in the event of a defect is limited to the correction of the defect by repair, replacement, or refund of the purchase price, at RADIO SHACK'S election and sole expense. RADIO SHACK has no obligation to replace or repair expendable items.
- B. RADIO SHACK makes no warranty as to the design, capability, capacity, or suitability for use of the Software, except as provided in this paragraph. Software is licensed on an "AS IS" basis, without warranty. The original CUSTOMER's exclusive remedy, in the event of a Software manufacturing defect, is its repair or replacement within thirty (30) calendar days of the date of the Radio Shack sales document received upon license of the Software. The defective Software shall be returned to a Radio Shack Computer Center, a Radio Shack retail store, a participating Radio Shack franchisee or Radio Shack dealer along with the sales document.
- C. Except as provided herein no employee, agent, franchisee, dealer or other person is authorized to give any warranties of any nature on behalf of RADIO SHACK.
- D. **EXCEPT AS PROVIDED HEREIN, RADIO SHACK MAKES NO EXPRESS WARRANTIES, AND ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES SET FORTH HEREIN.**
- E. Some states do not allow limitations on how long an implied warranty lasts so the above limitation(s) may not apply to CUSTOMER

III. LIMITATION OF LIABILITY

- A. **EXCEPT AS PROVIDED HEREIN, RADIO SHACK SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED OR ALLEGED TO BE CAUSED DIRECTLY OR INDIRECTLY BY "EQUIPMENT" OR "SOFTWARE" SOLD, LEASED, LICENSED OR FURNISHED BY RADIO SHACK, INCLUDING, BUT NOT LIMITED TO, ANY INTERRUPTION OF SERVICE, LOSS OF BUSINESS OR ANTICIPATORY PROFITS OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OR OPERATION OF THE "EQUIPMENT" OR "SOFTWARE," IN NO EVENT SHALL RADIO SHACK BE LIABLE FOR LOSS OF PROFITS, OR ANY INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES ARISING OUT OF ANY BREACH OF THIS WARRANTY OR IN ANY MANNER ARISING OUT OF OR CONNECTED WITH THE SALE, LEASE, LICENSE, USE OR ANTICIPATED USE OF THE "EQUIPMENT" OR "SOFTWARE."** NOTWITHSTANDING THE ABOVE LIMITATIONS AND WARRANTIES, RADIO SHACK'S LIABILITY HEREUNDER FOR DAMAGES INCURRED BY CUSTOMER OR OTHERS SHALL NOT EXCEED THE AMOUNT PAID BY CUSTOMER FOR THE PARTICULAR "EQUIPMENT" OR "SOFTWARE" INVOLVED.
- B. RADIO SHACK shall not be liable for any damages caused by delay in delivering or furnishing Equipment and/or Software.
- C. No action arising out of any claimed breach of this Warranty or transactions under this Warranty may be brought more than two (2) years after the cause of action has accrued or more than four (4) years after the date of the Radio Shack sales document for the Equipment or Software, whichever first occurs.
- D. Some states do not allow the limitation or exclusion of incidental or consequential damages, so the above limitation(s) or exclusion(s) may not apply to CUSTOMER.

IV. SOFTWARE LICENSE

- RADIO SHACK grants to CUSTOMER a non-exclusive, paid-up license to use the TANDY Software on **one** computer, subject to the following provisions:
- A. Except as otherwise provided in this Software License, applicable copyright laws shall apply to the Software.
 - B. Title to the medium on which the Software is recorded (cassette and/or diskette) or stored (ROM) is transferred to CUSTOMER, but not title to the Software.
 - C. CUSTOMER may use Software on a multilaser or network system only if either, the Software is expressly labeled to be for use on a multilaser or network system, or one copy of this software is purchased for each node or terminal on which Software is to be used simultaneously.
 - D. CUSTOMER shall not use, make, manufacture, or reproduce copies of Software except for use on **one** computer and as is specifically provided in this Software License. Customer is expressly prohibited from disassembling the Software.
 - E. CUSTOMER is permitted to make additional copies of the Software **only** for backup or archival purposes or if additional copies are required in the operation of **one** computer with the Software, but only to the extent the Software allows a backup copy to be made. However, for TRSDOS Software, CUSTOMER is permitted to make a limited number of additional copies for CUSTOMER'S own use.
 - F. CUSTOMER may resell or distribute unmodified copies of the Software provided CUSTOMER has purchased one copy of the Software for each one sold or distributed. The provisions of this Software License shall also be applicable to third parties receiving copies of the Software from CUSTOMER.
 - G. All copyright notices shall be retained on all copies of the Software.

V. APPLICABILITY OF WARRANTY

- A. The terms and conditions of this Warranty are applicable as between RADIO SHACK and CUSTOMER to either a sale of the Equipment and/or Software License to CUSTOMER or to a transaction whereby Radio Shack sells or conveys such Equipment to a third party for lease to CUSTOMER.
- B. The limitations of liability and Warranty provisions herein shall inure to the benefit of RADIO SHACK, the author, owner and/or licensor of the Software and any manufacturer of the Equipment sold by Radio Shack.

VI. STATE LAW RIGHTS

- The warranties granted herein give the **original** CUSTOMER specific legal rights, and the **original** CUSTOMER may have other rights which vary from state to state.

Connecting the Acoustic Coupler 2 to the Computer

1. Connect the DIN connector to the **PHONE** connector on your Computer.
2. Set the **DIR/ACP** switch on your Computer to **ACP**.
3. Dial the phone and wait for the other party to answer. You might need to talk over the phone (to set communication protocol, for example).
4. When you hear a high-pitched tone, place the earpiece unit securely over the earpiece of a standard telephone handset; place the speaker unit over the mouthpiece of the handset, then enter the terminal mode on your computer.

Note: Be sure that the acoustic cups are firmly linked with the handset, or poor acoustic characteristics will result.

Position the coupler cable so that it is perpendicular to the coupling units and the handset.




Figure 1

5. When the earpiece and mouthpiece units are coupled to the handset, place them on a flat surface as shown in Figure 2.

Note: Avoid laying the handset on its side on any hard surface, such as a desk, because this will allow exterior vibrations to be picked up; thus, data errors could result. When possible, it is recommended that the Acoustic Coupler 2 be placed on a one-inch thick piece of low-density foam.

Correct positioning of the handset with the Acoustic Coupler 2 unit in place.




Figure 2

Incorrect positioning allows exterior vibrations to enter the handset; this could cause data errors.




Figure 3

6. Connection is now complete.

Note: See the owner's manual of your computer for specific instructions regarding use of Acoustic Couplers with your computer.

Connecting the Acoustic Coupler 2 to the DCM-6

By connecting your Acoustic Coupler 2 to the DCM-6 Direct-Connect Modem (26-1393), you can avoid the more complex types of telephone connections. Just connect the DIN connector of the acoustic cups to the acoustic coupler jack of the DCM-6, as illustrated in Figure 4. For further information, refer to the DCM-6 operation manual.




Figure 4

Note: Modem operation with acoustic cups is not as reliable as direct-connect operation.

Specifications

Applicable Telephone Type	Type 500 (Rotary Dial)/Type 2500 (Pushbutton) with standard or European-style handset	
Communication Mode	Full/Half-duplex	
Modulation Type	F.S.K.	
Data Rate	300 baud	
Operation Mode	Originate/Answer	
Transmitting Frequency	Originate: Answer:	1070 to 1270 Hz 2025 to 2225 Hz
Receiving Frequency	Originate: Answer:	2025 to 2225 Hz 1070 to 1270 Hz
Transmitting Sound Pressure Level	Less than 1 N/m ² (0.3 to 3.4 kHz)	
Carrier Detection Level	Half-Duplex: Full-Duplex:	-40 dBm -30 dBm
Environmental Noise Allowance	Less than 80 dB	
Operating Voltage	+5V	
Power Consumption	Less than 30 mW	
Operating Temperature Range	40°F to 104°F (5°C to 40°C)	
Operating Humidity Range	20% to 80% RH (non-condensing)	
Dimensions	3" (diameter) × 3-1.8" (height) 78 mm (diameter) × 79.5 mm (height)	
Weight	13 oz (380 g) including cable	

To avoid data errors and obtain the longest-service life, do not use the Acoustic Coupler 2 where it will be:

- Subjected to extremely high or low temperatures or high humidity.
- Exposed to excessive vibration.
- Surrounded by excessive exterior noises.
- Close to very high voltage or appliances using a high voltage.

SERVICE POLICY

Radio Shack's nationwide network of service facilities provides quick, convenient, and reliable repair services for all of its computer products, in most instances. Warranty service will be performed in accordance with Radio Shack's Limited Warranty. Non-warranty service will be provided at reasonable parts and labor costs.

6/86

RADIO SHACK
A Division of Tandy Corporation
Fort Worth, Texas 76102